

DRILLING A HOLE THROUGH THE BOND BEAM – R-5

Holes may be drilled through the (top) bond beam for wiring and plumbing drops. See the drawing below for proper hole placement.

CAUTION: Carefully follow drawing below to avoid contact with steel reinforcement.
Do NOT cut or drill into any Superior Walls stud.

