

ATTACHING BASEBOARD TO SUPERIOR WALLS

The following details provide possible methods that may be used to attach baseboard to a Superior Walls panel.

NOTE: For garages or utility rooms where you plan to introduce excess water, consider using PVC trim (like Azek) and moisture resistant drywall. The footer beam area of the Superior Walls stud cavities could also be filled with spray foam (behind the PVC trim).

